

1.- REMOVE HOOKS IF ANY. REMOVE PLASTIC INSERT IN TOW HOOK AREA AND THE 4 CLIPS (2 ON TOP, 2 ON BOTTOM).

2.- SLIDE BRACKET THROUGH THE BUMPER OPENING AND AGAINST THE FRAME AS SHOWN (NOTE: THERE IS A LEFT SIDE AND RIGHT SIDE BRACKET).

3.- IF TAHOE/SUBURBAN HAD TOW HOOKS, PLACE THEM BACK IN THE FRAME AND USE ONE OF THE SHORT TOW HOOK BOLTS AND ONE ½" X 5" BOLT TO INSTALL BRACKET PER EACH SIDE.

4.- IF TAHOE/SUBURBAN DOES NOT HAVE TOW HOOKS, USE THREE ½" X 1 ½" BOLTS TO INSTALL BRACKETS ON BOTH SIDES.

5.- PLACE BRACKET AGAINST THE FRAME AND TIGHTEN ALL BOLTS.

6.- FASTEN GRILLGUARD TO THE OUTSIDE OF THE MOUNTING BRACKETS WITH TWO ½" X 1 ½" BOLTS ON EACH SIDE.

5.- CHECK ALIGNMENT AND TIGHTEN BOLTS.

10 - ½" x 1½" bolts

2 - ½" x 5" bolts

12 - ½" nuts

12 - ½" lock washer

24 - ½" flat washer

## INSTALLATION FOR PART NO. 1111 2007 CHEVY TAHOE/SUBURBAN GRILLGUARD

