

GAGE MOUNTING
INSTRUCTIONS
FOR #2315 (FORD 150
REPLACEMENT)

1. Remove Front End bumper.
2. Place Front End replacement and bolt on to frame support as shown:

