

# 05-08 Colorado

- 4.- 1/2 X 4 1/2 " bolts
- 8.- 1/2 X 1 1/2" bolts
- 12.- 1/2 nuts
- 12.- 1/2 lock washer
- 24.- 1/2 flat washer

1114

- Step 1 First place boot shape bracket between frame as shown : bolt on with 2.- 1/2 x 4 1/2" bolts on each side.
- Step 2 On the side of the frame close to the front. There is a bracket welded to the frame. Remove top factory bolt and then place "C" bracket on top of frame bracket. Use the same factory bolt as shown :
- Step 3 Remove or notch bottom plastic trim.
- Step 4 Place grill guard on the outside of the boot bracket and bolt on with 2 .- 1/2 X 1 1/2" bolts on each side.
- Step 5 Place flat bar bracket on top of the "C" bracket and on the grill guard tabs as shown:
- Step 6 Check alignment and tighten bolts.

Note : You may need to periodically retighten the bolts.

