



1.- REMOVE PLASTIC BETWEEN RADIATOR AND GRILL, THEN REMOVE GRILL TO HAVE ACCESS TO FRAME.

2.- ALL BOLTS USED ARE $\frac{1}{2}$ " x $1\frac{1}{2}$ ". BOLT SMALL "Z" BRACKET TO FRAME AS SHOWN, THEN "L" BRACKET TO TOP OF "Z" BRACKET,

3.- NOW BOLT BOTTOM SUPPORT BRACKET TO BOTTOM AREA OF FRAME WITH THE TOW HOOKS ON EACH SIDE.

4.- MOUNT GRILLGUARD AND ATTACH TO THE SHORT LEG OF "L" BRACKET WITH BOLTS.

5.- FASTEN GRILLGUARD TO THE OUTSIDE OF THE BOTTOM BRACKETS WITH ONE BOLT ON EACH SIDE.

5.- CHECK ALIGNMENT AND TIGHTEN BOLTS.

INSTALLATION FOR
PART NO. 1123
2007 CHEVY 1500
SILVERADO NEW BODY
GRILLGUARD