

INSTALLATION FOR PART NO. 1216 06-08 DODGE 2500/3500 RAM GRILLGUARD

Step 1: Remove nuts on inside factory bolts and attach the inside mounting bracket to them on the outside of the frame. The bracket should have the 3" tab on the top pointing to the center of the truck. Fasten nuts loosely to allow adjustment later.

Step 2: Attach the flat 11" top bracket to the top tab of the inside bracket that should show above the bumper.

Step 3: Position grillguard so that the inside mounting bracket attached to the frame is between the top flat bracket and the bottom flat bracket on the grillguard.

Step 4: Position the grillguard so that the top flat bracket sits above the tab on the upright. The bottom bracket of the grillguard should fit below the bottom tab of the inside mounting bracket that should show right below the bumper.

Step 5: Align and tighten nuts and bolts.

