



INSTALLATION FOR PART NO. 1424 2007 GMC HD GRILLGUARD

1.- REMOVE THE TWO FACTORY SIDE NUTS CLOSE TO THE FRONT OF FRAME.

2.- YOU MAY HAVE TO PUT FACTORY BOLT BRACKET INSIDE OUT ON DRIVER SIDE TO BOLT IT ON THE OUTSIDE OF THE FRAME AS SHOWN.

3.- PLACE BOTTOM BRACKET ON THE OUTSIDE OF THE FRAME THROUGH THE TOW HOOK OPENING AND BOLT ON WITH THE FACTORY BOLTS AS SHOWN.

4.- REMOVE INSIDE FACTORY BUMPER BOLT THAT IS ABOVE FRAME. PLACE "Z" BRACKET FACING IN AND BOLT ON WITH FACTORY BOLT.

5.- PLACE TOP FLAT BRACKET TO THE INSIDE "Z" BRACKET AS SHOWN.

6.- PUT GRILLGUARD IN PLACE, BOLT ON BOTTOM BRACKET TO INSIDE OF GRILLGUARD AND THEN THE TOP "Z" BRACKET.

7.- CHECK ALIGNMENT AND TIGHTEN BOLTS. PERIODICALLY RETIGHTEN BOLTS.