

GAGE FRONT END REPLACEMENT
MOUNTING INSTRUCTIONS
FOR
#2135

1. Remove Front Bumper
2. Mount Replacement inside of box frame as shown and bolt.

